



# Jett Sett

Basic<sup>™</sup>

50 grams

Commercial Sample

**Know More**

## DIRECTIONS:

1) Heat water in a hot pot, electric pickler, or in the microwave oven (the amount of water should be enough to cover the surface area of the amount of **Jett Sett Basic<sup>™</sup>** material that is required).

2) Use a thermometer to ensure that the water is not heated more than 75 °C.

**DO NOT HEAT MORE THAN 75 °C,**  
or the material might lose its properties!

3) Pour the desired amount of **Jett Sett Basic<sup>™</sup>** into the heated water. After a few minutes it will soften. As the materials heats and softens it will turn from white colour to semi-transparent.

4) Use tweezers or tongs to remove the heated material from the hot water. Use caution in handling the heated material and squeeze **Jett Sett Basic<sup>™</sup>** with your hands to remove excess water.

5) Form the material into the desired shape or fill it into the fixture, which will hold your small parts (e.g. stone setting, engraving etc).

6) Allow the material to harden. Submerge it into cold water; place it in the fridge or use you mold chiller to expedite the hardening process.

# Jett Sett

from

COOL TOOLZ

**Nagesh: 99000 44332**

# 73-C-2, 2nd Floor,  
Electronics City,  
Bangalore, Karnataka 560100

[cooltoolzblore@gmail.com](mailto:cooltoolzblore@gmail.com)

[cooltoolz.co.in](http://cooltoolz.co.in)